

# WMC Novice Scoreboard Instructions

Press **GAME TIME**, **GAME TIME** to clear the scoreboard.

## Warm-up:

Press **TIME**, **3**, **ENTER** to set a 3 minute warm-up.

Press **STOP/GO** to start it running at any time or to stop the clock if you want to lengthen the warm-up time (eg. if teams or officials are not ready).

Do **NOT** use **INTERM/WARMUP** as it buzzes without allowing you to change the time. Instead set the warmup as a period.

## Starting the game:

Press **GAME TIME**, **GAME TIME** to clear the scoreboard.

Press **TIME**, **MM**, **ENTER** to enter the number of minutes (MM) for the first period.

*Ex. For Novice with two 20 minute periods press **TIME**, **20**, **ENTER***

Press **STOP/GO** to start or stop the clock.

The scoreboard will assume all subsequent periods are the same length.

## Programmable Interval Horn:

An interval horn can be set to sound time durations of 1 – 9 minutes or 10 – 1:59 seconds.

Press **TIME**, **HORN** M or SS, **ENTER**

It will be cancelled when the period ends or by entering 0 for the time.

*Ex. If a Novice team needs an interval horn set every 1:30 minutes, do the following:*

*Press **TIME**, **HORN** 130, **ENTER***

*To clear this interval horn, do the following:*

*Press **TIME**, **HORN** 0, **ENTER***